


MOUNTING INSTRUCTIONS

LINKAGES' COMPONENTS (all the following parts are included in the bag)			USE WITH VALVES (Models - DN)					
			MVF				MVF59A/C	
			VSF - 15,25 MJF - 20,25 MZ, VZ - 15+50	VSF - 20,32+50 MJF - 15,32+50	VZF MZF 65+100	VZF MZF 125+150	VZ/MZ	
Q	Position Number							
1	A*	Neck adapter for 1 3/8"	X	X			X	X
1	B*	Neck adapter for 1 1/4"			X	X		
1	C	Lock nut for 1 3/8"		X				X
1	D*	Stem adapter for 1/4" (Short L=55 mm)	X					X
1	E*	Stem adapter for 1/4" (Medium, L=70 mm)		X			X	
1	F*	Stem adapter for 1/4" (Long, L=109 mm)			X			
1	G*	Stem adapter for 3/8" (L=55 mm)				X		
2		M8 Nuts			X			
1		3/8" Stem nut				X		
1		1/4" Stem nut	X	X	X			X

* Letter stamped on the component




Le caratteristiche contenute in questa pubblicazione possono essere modificate senza preavviso

1 Emissione 11/10 2 DIM184

MOUNTING INSTRUCTIONS

LINKAGES' COMPONENTS (the following parts are included in the bag)			USE WITH VALVES (Models - DN)								
QTY	Position Number		MVH56FA-MVH46-MVH26				MVH56FC				
			VSF - 15,25 MJF - 20,25 MZ, VZ - 15÷50	VSF - 20,32÷50 MJF - 15,32÷50	VZF MZF 65÷100	VZF MZF 125÷150	VSF - 15,25 MJF - 20,25 MZ, VZ - 15÷50	VSF - 20,32÷50 MJF - 15,32÷50	VZF MZF 65÷100	VZF MZF 125÷150	
1	A*	Neck adapter for 1 3/8"	X	X				X	X		
1	B*	Neck adapter for 1 1/4"			X	X				X	X
1	C	Lock nut for 1 3/8"		X					X		
1	F*	Stem adapter for 1/4" (Long, L=109 mm)	X	X				X	X	X	
1	H*	Stem adapter for 1/4" (Extra-long, L=120 mm)			X						
1	L*	Stem adapter for 3/8" (Long, L=70 mm)				X					X
1		M8 Stem nut						X			
1		3/8" Stem nut					X				X
1		1/4" Stem nut	X	X	X			X	X	X	

* Letter stamped on the component



Le caratteristiche contenute in questa pubblicazione possono essere modificate senza preavviso

1 Emissione 11/10 2 DIM185